



ROLLER/HAWSE FAIRLEAD 12" LIGHT BRACKET

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

KIT CONTENTS
12+Led Light Mount

TOOLS NEEDED
17mm Socket / Wrench
19mm Socket / Wrench



Hawse Fairlead



Roller Fairlead

INSTALLATION INSTRUCTIONS

1. Remove the bolts in the from your roller or hawse fairlead using a 17mm or 19mm socket and wrench. Retain hardware.
2. Place the bracket behind the roller or hawse fairlead and reinstall the hardware. Tighten with a 17mm or 19mm socket and wrench. **See Photo 1.**
3. Install the 12+LED light between two tabs and tighten with the supplied bolts that came with the light. **See Photo 2.**
4. Wire the light with the supplied light instructions.



PHOTO 1



PHOTO 2

Thank You for choosing Rough Country for your off road needs!!!