



2010-up Dodge 2500/3500 20" LED LIGHT MOUNT

Rough Country recommends this system be installed by a certified technician. In addition to these instructions, professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle.

Please read instructions before beginning installation. Check the kit hardware against the Kit Contents List. Be sure you have all needed parts and know where they go.

PRODUCT USE INFORMATION

Do not add, alter, or fabricate any factory or after-market parts to increase vehicle height over the intended height of the Rough Country product purchased. Mixing component brands is not recommended. Rough Country will not be responsible for any product that is altered.

If question exist, please call us @ 1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products.

Kit Contents:

2—Dodge LED Light Brackets

1—70205Bag2:

8-12mm x 45mm Bolts

8-1/2+Flat Washer



Tools Needed:

18mm Socket

19mm Socket

INSTALLATION INSTRUCTIONS

1. Using a 18mm socket remove the four factory bolts holding each tow hook.
2. Place the bracket behind each tow hook (with the light tab to the inside) and insert the tow hook back onto the truck using the supplied 12mm x 45mm bolts and washers. Hand tighten. **See Photo 1.**
3. Install the 20+light bar between the brackets and tighten with the supplied bolt that came with the light. **See Photo 2.**
4. Tighten tow hook bolts with a 19mm socket.
5. Wire the light with the supplied light instruction sheet.



Photo 1



Photo 2